

## Installing Your Wired ACS GPS Tracking Device

## **Install the Device**

## To prepare for the installation you will need to:

- Review product and parts: Your shipping package should include the ACS tracking device complete with a wiring harness.
- Research your vehicle: Through your owner's manual or online obtain the wiring diagram for the MAKE/MODEL/YEAR of your vehicle.
- Gather needed tools/parts: Needed tools may include: Screwdrivers, Wire Strippers and Cutters, Crimping Tool, Voltmeter, Zip Ties, and Velcro Strips.

Wiring the device into a vehicle is an easy installation. The ACS wired device has a series of wires; you will only need to attach three of these wires to your vehicle (the additional wires are for future features or functions). The three wires you need are:

The **Red** Wire (Power),

The longer of the two **Black** Wires (Ground)

The White Wire (IGNITION SENSE).

Follow these steps to install the device:

- 1. Find the constant Red Power Wire in your vehicle. Cut and strip this wire.
- 2. Cut and strip the Red Wire on the GPS device.
- 3. Connect the two Red Wires and crimp. This connection provides power to the device.
- 4. Strip the Black Wire on the GPS device.
- 5. Connect the ACS Black Wire to your vehicle's chassis. This connection serves as a ground for the device.
- 6. Locate the vehicle's ignition wire (reference the vehicle's wiring diagram in order to locate).
- 7. Verify the Ignition Wire by measuring the operating voltage while the key is turned to the ON or START position (the voltage should read 0 VDC when the key is in the off position, and typically between 11V and 14V when in the ON position).
- 8. Strip the White Wire on the ACS device.
- 9. Connect the White Wire on the ACS device to the vehicles Ignition Wire. This connection allows the ACS device to report ignition OFF and ON events.
- 10. An optional plastic zip tie is included to secure the device under the vehicle dash with the label that reads (Label Side Down) facing down.

## If you have difficulties

Please contact ACS Customer Support: Phone: 1-470-443-9000 Ext. 104

Email: gpsservice@ACScommunications.com

	Blinking 1x/second	Searching for a GSM Network
	Blinking	
Cell (Blue)	1x/3seconds	GSM Lock
	Off	Modem Reboot
GPS (Green)	Solid	Searching for Satellite
	Blinking	GPS Lock